

4F-1, 236, Fu-Te 2nd Rd., His Chih,

Taipei Hsien, 221, Taiwan

TEL:886-2-6616-6692 · 2694-6687

FAX:886-2-2694-6875 · 2694-5097

Innovation With a Human Touch

Control Panel Changing Process Spirit

Version: 1.0 May 20, 2014




Revision History :

Version	Date	Page	CONTENTS
1.0	May, 20 2014		First release



1. Dismount 2 screws of top cover(M4 *8)








2. Lift the top $cover_{\circ}$




3. Please turn the safety lock switch to LOCK status according to the direction shown on the sticker (see picture) to avoid the collapsing of top cover.









4. Dismount 4 screws for cover of control panel and ground cable screw.

5. After control panel cover is removed, there are 4 screws needs to be removed and the five cables (in the red circle). Then the control panel can be removed and changed new one.

